

## 2.018 CLEANING SAMS DRAWER SCREENS

(podfall000712)

Page 1 of 3 pages

### OBJECTIVE:

Clean the Space Acceleration Measurement System II (SAMS II) Drawer Screens.

### TOOLS:

Vacuum Cleaner SEG39125637-303 (if necessary)

### MATERIALS:

Gray Tape, 2" width

#### NOTE

1. The RTS/D1 and ICU/D1 drawers are located in EXPRESS Rack 1 at LAB1O2. The RTS/D2 drawer is located in EXPRESS Rack 4 at JPM1F5.
2. The power to RTS/D1, RTS/D2, and ICU/D1 was removed by the **POIC**.
3. The drawer screens can be cleaned with either tape or the vacuum (if debris is heavy).

LAB1O2\_F1 1. sw DRAWER-1 POWER → OFF  
✓Power Lt – Off

sw DRAWER-2 POWER → OFF  
✓Power Lt – Off

LAB1O2\_L1 2. cb DWR PWR → OFF  
(RTS/D1)  
cb FAN PWR → OFF

SE cable EA12305-01 ←|→ CH A J6 (on RTS drawer front)  
SE cable EA12304-01 ←|→ CH B J7 (on RTS drawer front)

LAB1O2\_L2 3. Open access door (two captive fasteners).  
(ICU/D1)

cb PCB Fan → OFF  
cb DWR Fan → OFF  
cb POWER → OFF

Close access door (two captive fasteners).

LAB1O2\_L1 4. Pull drawer out until temperature indicator is visible.  
(RTS/D1)

#### NOTE

1. The touch temperature indicator has seven temperature squares in 5 deg C increments.
2. The squares change color based on the surface temperature of the drawer:  
Green indicates it is the actual temperature.  
Brown indicates it is above the actual temperature.  
Blue indicates it is below the actual temperature.

5. ✓Temperature indicator < 45°C

## 2.018 CLEANING SAMS DRAWER SCREENS

(podfall000712)

Page 2 of 3 pages

```
*****
*
* If the temperature is  $\geq 45^{\circ}$  C
* |   Push drawer in.
* |   Wait 30 minutes.
* |   Go to step 4
*
*****
```

6. Slide drawer out until screens are visible.
7. Remove lint from screens (four, two on each side of drawer) [Gray Tape, 2" width or Vacuum Cleaner].
8. Slide drawer back into rack.  
✓Drawer Handles – Closed, Locked
9. Repeat step 4 to step 8 for LAB1O2\_L2 (ICU/D1)

### NOTE

The DRAWER POWER, DWR and FAN lights will not illuminate until power is restored by **POIC**.

LAB1O2\_L1 (RTS/D1) 10. SE cable EA12305-01 →|← CH A J6 (on RTS drawer front)

SE cable EA12304-01 →|← CH B J7 (on RTS drawer front)

cb DWR PWR → ON

cb FAN PWR → ON

LAB1O2\_L2 (ICU/D1) 11. Open access door (two captive fasteners).

cb PCB Fan → ON

cb DWR Fan → ON

cb POWER → ON

Close access door (two captive fasteners).

LAB1O2\_F1 12. sw DRAWER-1 POWER → ON  
sw DRAWER-2 POWER → ON

13. Transfer Gray Tape, 2" width and Vacuum Cleaner to JPM to clean the RTS/D2 screens.

JPM1F5\_F1 14. sw DRAWER-2 POWER → OFF  
✓Power Lt – Off

JPM1F5\_L2 (RTS/D2) 15. cb DWR PWR → OFF  
cb FAN PWR → OFF

16. Pull drawer out until temperature indicator is visible.

## 2.018 CLEANING SAMS DRAWER SCREENS

(podfall000712)

Page 3 of 3 pages

### NOTE

1. The touch temperature indicator has seven temperature squares in 5 deg C increments.
2. The squares change color based on the surface temperature of the drawer:
  - Green indicates it is the actual temperature.
  - Brown indicates it is above the actual temperature.
  - Blue indicates it is below the actual temperature.

### 17. ✓Temperature indicator < 45°C

\*\*\*\*\*  
\*  
\*  
\* If the temperature is ≥ 45°C  
\* | Push drawer in.  
\* | Wait 30 minutes.  
\* | Go to step 16  
\*  
\*\*\*\*\*

18. Slide drawer out until screens are visible.

19. Remove lint from screens (four, two on each side of drawer) [Gray Tape, 2" width or Vacuum Cleaner].

20. Slide drawer back into rack.

✓Drawer Handles – Closed, Locked

### NOTE

The DRAWER POWER, DWR and FAN lights will not illuminate until power is restored by **POIC**.

21. cb DWR PWR → ON

cb FAN PWR → ON

JPM1F5\_F1 22. sw DRAWER-2 POWER → ON

23. Stow:

Gray Tape, 2" width

Vacuum Cleaner (if required)

24. Notify **POIC** of the amount of debris removed from the screens (light, medium or heavy).